KEYBOARD SHORTCUTS FOR CANVAS WORKSPACE

Canvas Workspace for PC – The official name for the version of Canvas Workspace that you download and install on your computer. **Canvas Workspace for Web** – The official name for the version of Canvas Workspace that you access via your internet browser.

NAME	DESCRIPTION	SHORTCUT	SHORTCUT
		(Canvas Workspace for PC)	(Canvas Workspace for Web)
New Project	Starts a new project.	Windows - CTRL N	Windows - N
		Mac- ₩ N	Mac - N
Save	Saves the current project.	Windows - CTRL S	Windows - S
		Mac-₩S	Mac - S
	, this will be saved as an FCM cut file this will be saved as a .CWPRJ file and		nt to save it to.
Save As	Saves as a new project.	Windows - CTRL SHIFT S	Shortcut Not Available.
		Mac-∺ SHIFTS	Function accessible through
			project menu.
0pen	Open a saved project.	Windows - CTRL 0	Shortcut Not Available.
		Mac- ₩ 0	Function accessible through
			project menu.
Export Transfer FCM File	Export cutting data for use	Windows - CTRL E	Shortcut Not Available.
	with your Scan N Cut.	Mac- ₩ E	Function accessible through
			download button on edit
			screen or download icon on
			library thumbnails.
Select Tool	Make the select tool the	Windows - V	Windows - V
	active tool.	Mac - V	Mac - V
Text Tool	Make the text tool the active	Windows - T	Shortcut Not Available.
	tool.	Mac - T	Function available through
			shapes library on edit screen.
Path Tool	Activates the path creator	Windows - P	Windows - P
	tool.	Mac - P	Mac - P
Freehand Path Tool	Activates the freehand path	Windows - Q	Windows - Q
	tool.	Mac - Q	Mac - Q
Hand Tool (Scroll)	Activates the hand tool	Windows - H	Tool Not Available.
	allowing you to move the mat	Mac - H	
	and objects around the		
	screen without affecting the		
	objects.		
Zoom Tool	Activates the zoom tool.	Windows - Z	Windows - Z
		Mac - Z	Mac - Z
Undo	To undo the last action(s)	Windows - CTRL Z	Windows - CTRL Z
	during editing a project.	Mac- ℋ Z	Mac- ₩ Z
Redo	Pressed undo to many times?	Windows - CTRL Y	Windows - CTRL Y
	Use this key combination to	Mac- ₩ Y	Mac - ₩ SHIFT Y
	redo some of the steps.		

NAME	DESCRIPTION	SHORTCUT	SHORTCUT
		(Canvas Workspace for PC)	(Canvas Workspace for Web)
Cut	'Cuts' the selected item from your project. You can then 'paste' it again or, if you do nothing and continue this is the same as deleting it.	Windows - CTRL X Mac - 光 X	Windows - CTRL X Mac - 光 X
Сору	Copies the currently selected item(s) in your project; you can then paste new copies with the paste shortcut.	Windows - CTRL C Mac - 光 C	Windows - CTRL C Mac - 光 C
Paste	Pastes the most recently cut or copied item(s). Repeated pressing of this key combination will paste more copies, one for each time your press it.	Windows - CTRL V Mac - 光 V	Windows - CTRL V Mac - 光 V
Duplicate	Creates a duplicate of the currently selected item(s). A quicker version of the cut/copy and paste method.	Windows - CTRL V Mac - 光 V	Windows - CTRL V Mac - 光 V
Duplicate Move	Similar to the duplicate shortcut however this option moves the duplicated object incrementally in the direction selected with the arrow key.	Windows & Mac - ALT and arrow key on the number pad of your keyboard.	Windows & Mac - ALT and arrow key on the number pad of your keyboard.
Move	Moves a shape or group incrementally in the direction selected.	Shortcut Not Available. Function available by pressing the arrow keys on the number pad of your keyboard.	Shortcut Not Available. Function available by pressing the arrow keys on the number pad of your keyboard.
Select All	Selects all shapes/objects in the current project.	Windows - CTRL A Mac - ₩ A	Windows - A Mac - A
Deselect All	Deselects all currently selected objects.	Windows - CTRL SHIFT A Mac - 光 SHIFT A	Shortcut Not Available. To deselect all objects, click anywhere in the design window.
Delete	Deletes the currently selected shapes/objects.	Windows - DELETE or BACKSPACE Mac - DELETE	Windows - DELETE or BACKSPACE Mac - DELETE
Weld	The outlines of multiple patterns are welded together to create a single outline.	Windows - CTRL 1 Mac - 光 1	Shortcut Not Available. Function available through edit menu.
Divide	When multiple patterns are overlapping, the outlines of the overlapped areas can be cut out as separate patterns. Outlines are created along the cutouts (overlapping area), creating new patterns.	Windows - CTRL 2 Mac - 光 2	Shortcut Not Available. Function available through edit menu.

NAME	DESCRIPTION	SHORTCUT	SHORTCUT
		(Canvas Workspace for PC)	(Canvas Workspace for Web)
Remove Overlapped	When multiple patterns are overlapping, the outlines of the overlapped areas are hidden, and outlines for those areas will not be created. The outlines that are hidden differ depending on the order in which the patterns are overlapping.	Windows - CTRL 3 Mac - 光 3	Shortcut Not Available. Function available through edit menu.
Subtract	When multiple patterns are overlapping, the shape on "top" will be subtracted from all selected patterns beneath it. The outlines that are created depend on the order in which the patterns are overlapping.	Windows - CTRL 4 Mac - 光 4	Shortcut Not Available. Function available through edit menu.
Delete Point (Path Editing Mode)	Deletes the currently selected node(s) whilst in path editing mode.	Windows - DELETE or BACKSPACE Mac - DELETE	Windows - DELETE or BACKSPACE Mac - DELETE
Show Layer	Makes the selected layer(s) visible in the workspace.	Windows - CTRL COMMA Mac - ₩ COMMA	Function Not Available. Whilst shapes/objects are
Hide Layer	Makes the selected layer(s) invisible in the workspace. It can still be selected unless it is also locked. Hidden layers may not be transferred when exporting a design.	Windows - CTRL SHIFT COMMA Mac - 光 SHIFT COMMA	applied in layers, there is no layers panel available in the online edition of Canvas Workspace.
Lock Layer	Locks the selected layer(s) so that they cannot be selected or exported.	Windows - CTRL L Mac - 光 L	
Unlock All	Unlocks all layers within a project.	Windows - CTRL SHIFT L Mac - ₩ SHIFT L	
Group	Groups all selected objects.	Windows - CTRL G Mac - ℋ G	Windows - G Mac - G
Ungroup	Returns grouped objects to individual shapes.	Windows - CTRL SHIFT G Mac - 光 SHIFT G	Windows - G Mac - G
Bring To Front	Moves the selected pattern(s) to the top of the layer stack.	Windows - CTRL SHIFT] Mac - 光 SHIFT]	Windows - CTRL SHIFT] Mac - 光 SHIFT]
Bring Forward (One Layer)	Moves the selected pattern(s) up one layer in the layer stack.	Windows - CTRL] Mac - 光]	Windows - CTRL] Mac - 発]
Send Backward	Moves the selected pattern(s) down one layer in the layer stack.	Windows - CTRL[Mac - 光 [Windows - CTRL [Mac - 発 [
Send To Back	Moves the selected pattern(s) to the bottom of the layer stack.	Windows - CTRL SHIFT[Mac - 光 SHIFT[Windows - CTRL SHIFT [Mac - ₩ SHIFT [

NAME	DESCRIPTION	SHORTCUT	SHORTCUT
		(Canvas Workspace for PC)	(Canvas Workspace for Web)
Zoom In	Zooms in towards the centre	Windows - CTRL +	Shortcut Not Available.
	of the mat by 10% each time	Mac - ₩ +	Function available via the
	shortcut is activated.		zoom tool or view menu.
Zoom Out	Zooms out from current view	Windows - CTRL -	
	by 10% each time shortcut is	Mac - ₩ -	
	activated.		
Show/Hide Ruler	Makes the on-screen ruler	Windows - CTRL R	Function Not Available.
	visible or invisible.	Mac- ℋ R	
Show/Hide Mat Image	Makes the on-screen image	Windows - CTRL M	Shortcut Not Available.
	of the cutting mat visible or	Mac-₩ SHIFT M	Function available via the
	invisible.		view menu.
Show/Hide Grid	Makes the on-screen grid	Windows - CTRL COLON	Function Not Available.
	visible or invisible.	Mac-∺ COLON	
Snap to Grid	Activates the snap-to-grid	Windows - CTRL SHIFT COLON	Function Not Available.
	function. Default snapping	Mac- ₩ ASTERISK	
	will be according to the		
	settings in the artboard tab		
	on the right of the workspace.		
Quit	Exits Canvas Workspace.	Windows - CTRL Q	Shortcut Not Available.
		Mac-₩ Q	Closing your browser window
			or logging out will quit Canvas
			Workspace for Web.
Minimize Windows	Mac Only.	Windows - Function Not	Windows - Function Not
	Minimize minimizes a single	Available.	Available.
	window (Canvas Workspace).	Mac- ₩ M	Mac-₩M
Hide Windows	Hide hides the entire	Windows - Function Not	Windows - Function Not
	application. The dock shows	Available.	Available.
	you running applications, and	Mac - ₩ H	Mac- ₩ H
	then shows or lists the		
	applications windows when		
	you click or click and hold,		
	respectively.		